


Operating manual Nespresso coffeemachine

The Nespresso coffee can be made with special capsules, that can be bought in the small shop at Landal Amerongse Berg.

- Rinse and fill the water tank.
- Press the Espresso button (small cup) or Lungo button (bigger cup) to activate the machine.
When the lights are blinking the machine is heating up. This takes approximately 25 seconds.
When the lights are on steadily the machine is ready for use.
- Lift the lever completely and insert a Nespresso capsule.
- Close the lever and place a cup under the coffee outlet.
- Press the Espresso (40 ml.) or the Lungo (110 ml.) button to start making coffee. Preparation will stop automatically.
- Remove the cup. Lift and close the lever to eject the capsule into the used capsule container.



** It is possible to adjust the quantity of water by holding the Espresso or Lungo button until you have the desired quantity. This will be the new standard amount.*